







## Replacement Sheet

**FIG. 2A**IMMEDIATELY AFTER  
SUCKING SALT WATER**FIG. 2B**CHANGE SALT INTO  
SALT WATER BY  
DELIQUESCENT**FIG. 2C**IMMEDIATELY AFTER  
AIR SUCTION BY  
CRANKING ETC.**FIG. 2D**CURRENT SUPPLY TO  
HEATING RESISTOR**FIG. 3**


## Replacement Sheet

**FIG. 4A**


IMMEDIATELY  
AFTER SUCKING  
SALT WATER

**FIG. 4B**


CHANGE SALT INTO  
SALT WATER BY  
DELIQUESCENT

**FIG. 4C**

CURRENT SUPPLY  
TO HEATING  
RESISTOR

**FIG. 4D**

IMMEDIATELY  
AFTER AIR  
SUCTION BY  
CRANKING ETC.



## Replacement Sheet

FIG. 5




FIG. 6

